



Roof Permits

Standard Operating Procedures

The City of Freeport adheres to and enforces the 2015 International Residential Codes, 2015 International Building Codes, and the 2014 National Electrical Code.

Please contact Texas Department of Insurance (TDI) 1-800-248-6032 or online at www.tdi.texas.gov/wind

Contractor must provide proof of Windstorm Application already submitted to TDI. (WPI-1)

- 150 mph wind speed per Code Tables.
- Asphalt shingles per ASTM D3462 and table R905.2.4.1

Roof inspection:

Outside visual

- Drip ledge
- Ridge vents
- Sanitary vent flashings
- Furnace and water heater exhaust flashings

Attic access

- Sanitary vents through roof
- Furnace and water heater exhaust through roof and clearances
- Check bottom side of roof for nail patterns. (six nails per shingle.)
- Check bottom side of roof for opening under ridge vents

After installation is complete the contractor must provide proof of Windstorm. (WPI-8)



Permisos de techo

Estándar de Procedimientos Operativos

La ciudad de Freeport se adhiere y hace cumplir los Códigos residenciales internacionales de 2015, los Códigos internacionales de construcción de 2015 y el Código eléctrico nacional de 2014.

Comuníquese con el Departamento de Seguros de Texas (TDI) al 1-800-248-6032 o en línea en www.tdi.texas.gov/wind

El contratista debe proporcionar prueba de la Solicitud de tormenta de viento ya enviada a TDI. (WPI-1)

Velocidad del viento de 150 mph según las tablas de códigos.

Tejas de asfalto según ASTM D3462 y tabla R905.2.4.1

Inspección del techo:

Exterior visual

- Repisa de goteo
- Ventilaciones de cresta
- Tapajuntas de ventilación sanitaria
- Tapajuntas de escape de hornos y calentadores de agua

Acceso al ático

- Ventilaciones sanitarias a través del techo
- Escape del horno y del calentador de agua a través del techo y espacios libres
- Revise la parte inferior del techo para ver si hay patrones de clavos. (seis clavos por teja).
- Revise la parte inferior del techo para ver si hay apertura debajo de las ventilaciones de la cumbrera

Una vez completada la instalación, el contratista debe proporcionar prueba de Windstorm. (WPI-8)